

12.8V150Ah

Long Life LiFePO4 Battery














Dimension:









Unit: mm

SAFETY

- + Long life type prismatic LiFePO4 cells.
- + Battery certification: UN38.3, MSDS.
- + The cycle life over 3500 times.

DESIGN

- + Detachable case, better than traditional case.
- Case material ABS+PC, better and stronger than ABS case.
- IP65 Class, water-proof design.
- Maintenance free.

BATTERY MANAGEMENT SYSTEM

- + Integrated BMS inside.
- + Independent protection for charge and discharge.
- + OVP, LVP, OCP, OTP, LTP, OTP, Short circuit protection.
- + Support LEDs indicators, Heater parts, Blue-tooth module.



12.8V150Ah

SPECIFICATION

Model	LFP12.8V150AH G1	LFP12.8V150AH G2
Nominal Voltage [V]	12.8	
Nominal Capacity [Ah]	150	
Total Energy [Wh]	1920	
Max. Charging Current [A]	100	
Recommended Charging Current [A]	75	
Charging Voltage [V]	14.2~14.6	
Max. Discharging Current [A]	100	
End of Dicharge Voltage [V]	11.2	
Operating Temperature Range ⁽¹⁾	Charge: 0 ~ +50°C; Discharge: -20 ~ +55°C With optional heater parts: Charge/Discharge -20~+55°C	
Protection	Over charge Over discharge, Over temperature, Low Temperature, Over Current, Short circuit	
Cycle Life (2)	>4000 cycles	
Designed Calendar Life	10 Years	
Dimension (W*D*H, mm)	330*173*214	
Weight [Kg]	15.5	
Operation Humidity	0~95% RH (No condensing)	
Communication Port	1	1
LED Indicator and Button	1	SOC, ALM, RUN, ON/OFF
IP Class	IP65	IP65
Parallel Support (3)	Yes, Max, 4Sets	Yes, Max, 4Sets
Series Support	Yes, Max. 4 Sets	Yes, Max. 4 Sets
Certification-Battery	UN38.3; MSDS; CE	
Optional Parts	Internal Bluetooth Module Heater Parts(100W)	Internal Bluetooth Module Heater Parts(100W)

Note

- (1) Normally the Li-ion battery operation temperature range is: discharge $-20 \sim +55$ °C, charge $0 \sim +55$ °C, If the optional heater is stalled, it will automatic start to work once the cell temperature is below 5°C and the heater can help to increase cell temperature $4 \sim 8$ °C/hour.With Optional Heater: Charge / Discharge: $-20 \sim +55$ °C, the charger power should be above than heater parts power consumption.
- (2) 25°C ,0.5C/0.5C, $100\%\,\text{DOD}$ and $80\%\,\,\text{EOL}$
- $(3) \ For parallel \ and \ series \ power \ cable \ connection, \ \ refer \ to \ user \ manual.$

The datasheet is subject to change without prior notification



BMS Detail Information

Over-Charge Alarm & Protection		
Over-Charge Alarm	3.55V (For cell) 14.2V (For pack)	
Over-Charge Protection	3.7V (For cell) 14.8V (For pack)	
Over-Charge Protection Delay	1000 ms	
Over-Charge Release	3.45V (For cell) 13.8V (For pack)	
Over-Discharge Alarm & Protection		
Over-Discharge Alarm	2.8V (For cell) 11.2V (For pack)	
Over-Discharge Protection	2.5V (For cell) 10V (For pack)	
Over-Discharge Protection Delay	1000 ms	
Over-Discharge Release	2.8V (For cell) 11.2V (For pack)	
Over Current Alarm & Protection		
Charge Over Current Alarm	82.5A	
Charge Over Current Protection	105A	
Charge Over-Current Protection Delay	158	
Charge Over Current Protection Release	Automatic release after 1min and up to 3 times or Discharge	
Discharge Over Current Alarm	105A	
Discharge Over Current Protection-1	110A	
Discharge Over Current Protection-1 Delay	15S	
Discharge Over Current Protection-2	300A	
Discharge Over Current Protection-2 Delay	200ms	
Discharge Over Current Protection Release	Automatic release after 1min and up to 3 times or Charge	
Over Temperature Alarm & Protection		
Charge Low Temperature Alarm	7°C	
Charge Low Temperature Protection	0°C	
Charge Low Temperature Protection Release	5°C	
Charge High Temperature Alarm	50°C	
Charge High Temperature Protection	55°C	
Charge High Temperature Protection Release	45°C	
Discharge Low Temperature Alarm	-10°C	
Discharge Low Temperature Protection	-20°C	
Discharge Low Temperature Protection Release	-17°C	
Discharge High Temperature Alarm	55°C	
Discharge High Temperature Protection	60°C	
Discharge High Temperature Protection Release	50°C	
Short Circuit Protection		
Short Current Protection Delay Time	1500 uS	
Short Current Release Method	Release load	
Heater Control (for optional heater parts)		
Heater ON	Cell temperature≤ 0°C and charger is connected	
Heater OFF	Cell temperature >10°C	